



HOT WATER HEATING CORRECTION FACTORS									
Entering Air Temp (F)	Entering Water Temperature (F)								
	100°	110°	120°	130°	140°	150°	160°	170°	180°
50°	.419	.500	.579	.665	.742	.838	.917	1.000	1.090
55°	.376	.460	.544	.629	.708	.791	.873	.963	1.048
60°	.335	.419	.500	.579	.665	.742	.838	.917	1.000
65°	.290	.376	.460	.544	.629	.708	.791	.873	.963
70°	.251	.335	.419	.500	.579	.665	.742	.838	.917
75°	.205	.290	.376	.460	.544	.629	.708	.791	.873
80°	.167	.251	.335	.419	.500	.579	.665	.742	.838

To determine actual capacity, multiply the listed capacity by the correction factor for the actual entering air and water temperatures. The correction factors can be used with published heating capacities at 180° entering water temperature (E.W.T.).

